


**FOLOMOV®**



525  
流明

**C2**

**产品参数**

灯珠	适用电池
CREE XT-E 灯珠	1 X 14300 锂离子电池


**规格参数**

模式		
极高亮	525 流明	1小时
高亮	150 流明	2小时
中亮	50 流明	6小时
低亮	10 流明	30小时
月光模式	1 流明	270小时

	77米 (最大射程)
	1482Cd
	2米
	12.4克
	φ17X16X45.5毫米

**IPX8**  
防水等级

**日用模式**



**锁定功能**

关机时三击进入锁定状态，指示灯闪三次，此时按键进入锁定状态。

**解锁功能**

锁定状态时三击解锁，指示灯闪一次，此时恢复按键功能。

**电池充电指示灯**

红灯：充电中。蓝灯：已充满。

**温馨提示**

- 1、旋开尾部装入符合要求的电池，注意将电池正极朝向手电头部。
- 2、若电筒长时间未使用，请将电筒内的14300电池取出，防止漏液。
- 3、不能将光线直射眼睛，避免对眼睛照成伤害。

**保修服务**

15天包换：自售出之日起15天内，在正常使用情况下，若出现产品质量问题，客户可选择更换新品或维修服务。

1年免费保修：自售出之日起1年内，用户在正常使用情况下，产品若出现质量问题，则享受免费维修服务。

终身有限保修：超过1年免费保修期后，我们将提供有偿保修，费用以实际更换材料费用为准，不另收取人工费用。

保修凭证：消费者需要售后服务时，可凭购物发票或收据与经销商联系，由经销商对消费者提供服务，我公司将对经销商提供服务支持，免费保修不包括由以下行为造成的损坏和故障：

1. 正常使用造成的磨损
2. 粗暴操作或者违反本手册内容的错误操作
3. 电池漏液或者不正确使用电池

想了解更多产品信息或者动态，请访问我司官方网站 [www.folomov.com](http://www.folomov.com)


**留名实业有限公司**

联系电话：86-(0)755 2376 9382

广东省深圳市龙华区大浪街道华繁路289号裕健丰科技园B栋403



**FOLOMOV®**



525  
LUMENS

**C2**

**Parameter**

LED	Battery
CREE XT-E LED	1 X 14300 Li-ion battery

**SPECIFICATIONS:**

Model		
Turbo	525 LM	1h
High	150 LM	2h
Medium	50 LM	6h
Low	10 LM	30h
Moonlight	1 LM	270h

	77meters
	1482Cd
	2m
	12.4 g
	φ17X16X45.5mm

**IPX8**  
waterproof rating

**Operation:**

ON: Quickly press the switch to access to memorized mode. When in this mode, quickly press the switch to cycle through other modes(low→med→high→turbo).

**Strobe, SOS and beacon:**

No matter the light is on or off, press the switch twice to access to strobe mode. When in strobe mode, press the switch twice to cycle between strobe, SOS and beacon. Press the switch quickly to get back to the memorized mode.

**Moonlight:**

When the light is off, keep pressing the switch to access to moonlight mode. Option 1: Press the switch quickly to access to memorized mode from moonlight mode. Option 2: Press the switch twice to access to strobe mode from moonlight mode.

OFF: Press the switch for 0.5s.

**Lockout function**

Lock: When the light is off, press the switch 3 times to lock the switch. LED will flash 3 times.

Unlock: Press the switch 3 times. LED will flash once.

**Battery charging indicator**

Red LED: charging. Blue LED: full charged.

**CAUTION**

1. Insert the battery with the anode side(+) towards flashlight head.
2. Pls remove the battery if the flashlight will not be used for long time.
3. Do not shine the light into eyes.

**Warranty Details**

1. 15 days free replacement: distributors/dealers will replace users a new C2 within 15 days of C2 purchase for any manufacturing defects if the

problem develops in normal use.

2. 1 year free repair: we will offer free repair within 1 year from the date of purchase if the problem develops in normal use.

3. Limited lifetime warranty: For C2 beyond the free repair warranty period, we provide lifetime repair but will charge for C2 parts. Distributors/dealers will notify users the cost of parts before repair.

4. Free warranty does not cover any damage or failure caused by:

- a. Normal wear
- b. Rough operation
- c. Battery leakage

For more info, please visit [www.folomov.com](http://www.folomov.com). Welcome to follow @folomovbrand on Facebook.

**LUMIN INDUSTRIAL LIMITED**

[www.folomov.com](http://www.folomov.com)

Room 403, Bld. B, Yujianfeng Industrial Park, No. 289 Huafan Rd., Longhua, Shenzhen, 518100 China  
Tel: +86 (0)755 23769382

