

# Aurora A3 Pro Keychain Flashlight

## 产品说明书 (CN)

# 产品特征:

- CREE XP-G3 6500K 或者 5000K,可选色温
- 330mAh 锂聚合物可充电电池
- Micro USB 充电带充电指示灯,约 90 分钟即可充满
- 正面电子按键支持单手操作
- 橘皮光杯,光斑更均匀
- 整体符合人体工程学设计,提供更佳的握持手感
- 双向口袋抱夹和尾部伞绳孔设计提供多种携带方式
- 尾部支持倒立
- IP66 生活防水

# 产品参数:

材料: 7075 航空铝合金

长度: 60.5mm 直径: 15.6mm 重量: 20 克 包装配件: 1\*说明书, 1\*不锈钢钥匙环, 1\*不锈钢抱夹 1\*USB 充电线, 1\*手绳, 1\*保修卡

## 操作方式:

- 1. 照明模式
- 一键极亮:按住开关不放,松开即灭
- 开机:快速双击(默认进入记忆模式)
- 换挡: 单击循环 月光-低-中-高
- 一键极亮: 开机状态下双击, 此状态下单击进入记忆档位
- 关机: 任意档位下长按 0.3 秒;
  或者任意档位下工作超过 3 分钟,单击关机
  记忆模式: 工作三分钟后记忆该档位,下次开机进入记忆档位

#### 2. 爆闪

- 开机:
  - 1) 关机状态下快速三击
  - 2) 在照明模式下任意档位快速三击
- ◆ 关机:单击

#### 工作状态下(非一键极亮)快速双击或者快速三击可切换到对应档位。

注: 高亮档和中亮档工作时,因为产生大量的热,手电亮度会在 100 秒内降到 100 流明

## 充电:

## 建议收到本产品后首次使用前先将手电充满电!

- 打开位于侧面的充电口,通过 Micro USB 线接入电源
- 充电指示灯:蓝色呼吸灯为充电,蓝色常亮即充满
- 充电时间: 90 分钟
- 截止电压: 2.4V

注: 当电量低时, 充电指示灯会变红提示需充电, 单击可关闭提示。

#### 警告!!

- 当手电筒点亮时,请勿直视发光体(LED)
- 请勿将本产品照射人眼或动物眼睛
- 年龄低于 12 岁的小孩未在监护人陪护下禁止使用本产品
- 为了产品可靠性,筒身与筒头密封,无法拆卸

#### 质保服务:

- 保修期:自购买日起2年
- 任何明显人为原因造成的功能故障或外观不良不在保修范围内

## **User Manual (EN)**

#### Features:

- CREE XP-G3 6500K or 5000K LED
- Powered by built-in 330mAh Li-po rechargeable battery
- Micro USB rechargeable with charging indicator, fully charged in about 90 minutes
- E-switch supports one-handed operation
- Orange peel reflector
- Ergonomic design provides better grip and hold
- Reversable pocket clip included, and paracord hole at tail
- Tail stand capability
- IP66 weather resistance

#### **Parameters**

Material: 7075 aerospace aluminum alloy

Length: 60.5mm / 2.38" Diameter: 15.6mm / 0.61"

Weight: 0.71oz

Accessory: 1\*User Manual, 1\*SS Key ring, 1\*SS Pocket clip, 1\*USB

Cable, 1\*Lanyard, 1\*Warranty Card

# Operation/User Interface

- 1. Illumination
- Momentary ON: Press and Hold, release to turn off
- Turn ON: Rapid double click (default from Memory mode)
- Switch mode: click to cycle thru Moonlight-Low-Med-High
- Turn Off:
  - 1) At any mode, long press the button 0.3s;
  - 2) Click to turn off when the light works at any mode over 3mins.

Memory: When the light worked at a mode over 3mins, it will be turned on from the memorized mode next time.

- 2. Strobe (Emergency mode)
- Turn ON
  - a) From off, triple click
  - b) From any mode of Illumination, triple click
- Turn Off: Click

When the light is working (except for Momentary on), rapid double-click or rapid triple-click can switch to the related mode.

Note: When the light is working at High mode or Medium mode, it will step down to 100 lumens in 100 seconds due to the massive heat generated.

# **Charging:**

# Highly recommend charging the light before the first use.

- Open the USB port cover and connect to a power source thru Micro USB cable
- Charging indicator: Breathing blue is charging, Solid blue is fully charged.
- Charging time: 90 minutes
- Cutoff voltage: 2.4V

Note: If the battery is low, the indicator will come on Red to remind recharging, click the button to turn the indicator off.

## Warning!!

- DO NOT look directly into the emitter when it's ON
- DO NOT point the light at human eyes or animal eyes
- Child under 12 years old is NOT permitted to use the light unsupervised.
- The flashlight was glue sealed for the reliability, and disassembly is not under warranty.

#### Warranty:

- 2 years international manufacturer warranty
- Any human-made malfunction or defective is out of warranty.



6500K/5000K	月光/Moonlight	低亮/Low	中亮/Medium	高亮/High	爆闪/Strobe
31,5	2	20	360	700	1
	2	15	260	450	1
(0)	30 Hours	8 Hours	1.5+95 mins	1.5+75 mins	1
	32 Hours	10 Hours	1.5+120 mins	1.5+90mins	1
	1080cd (6500K)				
	850cd (5000K)				
	90m (6500K)				
	75m (5000K)				
N.	1.5m				
~~	IP66 (weather resistance)				