

# USER MANUAL

## IN THE BOX

- 134,000cd
- 730m
- 1.5m
- MCCS
- IPXB
- 1976/6.55mAh (Including Battery)
- Working temperature: 0~40°C
- Rechargeable Li-ion Battery: 500mAh/3.6V (EN150)
- Li-ion Battery: 500mAh/3.6V (EN150)
- \*Note: data are tested per ANSI/PLATO FL 1:2019 standard in digital mode without flashlight.

### Table 2: USB Magnetic Charging Cable

Cable length	0.5m
Input	USB Type C DC 5V 3A
Output	USB-CV 4.2V 20A
Time to fully charge	About 4.5 hours

### Table 3: Flashlight

COOL WHITE	CCT: 5700-6000	CR170
TURBO	1500lm	20m
HIGH	650lm	170m
MEDIUM	150lm	20h
LOW	15lm	7.5 days
MOONLIGHT	0.5lm	72 days

### Table 4: Javelot

Powerful, Portable, Long-range EDC Flashlight.

### Figure 2 Charge

Red: Charging  
Green: Charging Completed

### Figure 3 Remove the insulating film

SIDE SWITCH OPERATION:  
Press and hold

### Figure 4 Lock/Unlock Turbo

Press and hold

### Figure 5 Moonlight

Press and hold

### Figure 6 Turbo

Press and hold

### Figure 7 Strobe

Press side button

### Figure 8 Change Brightness Level

Press and hold

### Figure 9 Mode Switching

Standard Mode / Tactical Mode

### Figure 10 Press lightly for Low Mode

Tap

### Figure 11 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 12 Press firmly for Turbo Mode

Press

### Figure 13 Press firmly and hold for momentary on (Turbo)

Press and hold

### Figure 14 Change from Low to Turbo

Press

### Figure 15 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 16 Press firmly and hold for momentary on (Strobe)

Press and hold

### Figure 17 Battery level indicator

Green: >60%  
Red: 5~10%  
Blink Red: <5%

### Figure 18 Press lightly and hold for momentary on (High)

Tap and hold

### Figure 19 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 20 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 21 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 22 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 23 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 24 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 25 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 26 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 27 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 28 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 29 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 30 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 31 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 32 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 33 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 34 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 35 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 36 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 37 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 38 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 39 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 40 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 41 Press lightly and hold for momentary on (High)

Tap and hold

### Figure 42 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 43 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 44 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 45 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 46 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 47 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 48 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 49 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 50 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 51 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 52 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 53 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 54 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 55 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 56 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 57 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 58 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 59 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 60 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 61 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 62 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 63 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 64 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 65 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 66 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 67 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 68 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 69 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 70 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 71 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 72 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 73 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 74 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 75 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 76 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 77 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 78 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 79 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 80 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 81 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 82 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 83 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 84 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 85 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 86 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 87 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 88 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 89 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 90 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 91 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 92 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 93 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 94 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 95 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 96 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 97 Press lightly and hold for momentary on (Strobe)

Tap and hold

### Figure 98 Press lightly and hold for momentary on (Medium)

Tap and hold

### Figure 99 Press lightly and hold for momentary on (Low)

Tap and hold

### Figure 100 Press lightly and hold for momentary on (Turbo)

Tap and hold

### Figure 101 Press lightly and hold for momentary on (Strobe)

Tap and hold